

1. Parts and Accessories



2. Connecting to the Club

You must connect the CIT with a telephone cable to a telephone socket before sending your transactions to Betting System.

2.1 Steps to Connect

1. Enter your Personal Identification Number (PIN) followed by <Enter>
2. Check your calling location on the top of the LCD
3. If you are calling from a different location, press the <Change Call Setting> and select the correct location
4. Connect the CIT to the telephone socket and press <Connect Now> and wait for reply
5. Disconnect the CIT from the telephone socket and check reply details

After the PIN is entered, it is not required to enter it again if the CIT remains switch on.

Please do not switch off or disconnect the cable while the CIT is making a call. If the CIT cannot get through the telephone line in the first attempt, it will automatically retry for two more times.

2.2 Change Call Setting

There are 5 types of call setting: "Local", "Private Exchange", "Racecourse (AUX)", "International — Auto" and "International — Auto (PABX)".

Check the calling location displayed on the top of the LCD. You can change the call setting if you are using the CIT in different location.

Local	When you are calling in Hong Kong
Private Exchange	When you connect your CIT to PABX Enter the number required to obtain an outside line and press <Enter>
Racecourse (AUX)	When you use CIT socket at Happy Valley/ Shatin Racecourse or at The Hong Kong Jockey Club's Clubhouse * Connect the CIT AUX jack to the CIT socket

2. Connecting to the Club

Int'l — Auto
When you communicate with Betting System through CIT outside Hong Kong
Enter the international call access code followed by the Hong Kong's country code (852), then press <Enter>

Example 1: Enter (011852) if calling from Canada

Example 2: Enter (01) if calling from Macau, then press <Enter>

Int'l — Auto (PABX)
When you connect your CIT to PABX outside Hong Kong
Enter the number required to obtain an outside line together with the international call access code followed by the Hong Kong's country code (852), and press <Enter>

International CIT users are solely responsible for any consequences arising from the use of CIT outside Hong Kong. Users should check whether the use of CIT in the country concerned is legally permitted. Users are also required to check the compatibility of the local telephone socket.

Bets made, placed or otherwise originated from the United States or its dependent territories through the Internet, telephone or other electronic or wire communication systems are not welcome by the Club.

3. User Settings

3.1 Language Selection

User can select the display language to English or Chinese.

1. Press <Settings> from the main page
2. Press <English> or <中文> to select language
3. Press <OK> to go back to main page

3.2 Other User

If you are not this CIT-8 holder, you can follow these steps to access your account:

1. Press <Settings> from the main page
2. Press <Other A/C>
3. Key in the other Betting Account number and press <Enter>
4. Press <OK>
5. Other Betting Account number will be displayed in the main page

To resume to this CIT-8 holder's account:

1. Press <Settings> from the main page
2. Press <Holder A/C>
3. Press <OK>
4. Then the CIT holder's account number will be displayed in the main page

3.3 Privacy Key

This function prevents unauthorised persons from using your CIT. This is an optional feature and requires you to set a personal 3-digit password to activate and cancel.

To activate this function:

1. Press <Settings> from the main page
2. Press <Privacy ON>
3. Key in your 3-digit password and press <Enter>

To cancel this function:

1. Press <Settings> from the main page
2. Press <Privacy OFF>
3. Key in your 3-digit password and press <Enter>

When the PRIVACY KEY is activated, the CIT will only function when you key in your 3-digit password. If you fail to key in the correct password after three attempts, the CIT will request you to key in your PIN and transmit it to Betting System. After connection is made with Betting System, the PRIVACY KEY function will be cancelled. Then you will be able to continue using the CIT.

3.4 Screen Contrast

This function allows you to adjust contrast of the screen.

1. Press <Settings> from the main page
2. Press <Contrast>
3. Adjust the contrast and then press <OK>
4. Press <OK> to go back to main page

3.5 Auto Off

The CIT will automatically switch off after a pre-set period of time when the function is activated.

1. Press <Settings> from the main page
2. Press <Auto Off>
3. Select from <ON> or <OFF> and then press <OK>
4. Press <OK> to go back to main page

3.6 Reset PIN

Users can reset their CIT security code in case they forgot it, customers are required to call Interactive Services Hotline 1880 before resetting the PIN

1. Press <Settings> from the main page
2. Press <PIN Setting>
3. Press <Reset PIN>
4. Input Security Code, press <Enter>

3.7 Change PIN

Users can change the PIN by this function.

1. Press <Settings> from the main page
2. Press <PIN Setting>
3. Press <Change PIN>
4. Input the New Pin of your choice
5. Input your existig PIN, press <Enter>


3.8 Font Size

Users can change the font size setting

1. Press <Settings>from the main page
2. Press
3. Select <Large> or <small> then press <ok>


3.9 Calculator

Enter the build-in calculator function of the CIT

1. From the top of the screen, press the calculator 
2. When done, press <Close > to go back to main page


3.10 Volume

This function allows you to adjust the volume of the CIT

1. From the top of the screen, press the volume  icon
2. Adjust the value of volume from 0 (mute) to 3 (max)
3. Press <OK> to go back to main page

3.11 Battery Level

This function allows you to check the current battery level of the CIT

1. From the top of the screen, press the battery  icon
2. Press <OK> to go back to main page